



# PODIUM PROS INC.

Speaking with Confidence

Verify orientation of shock mount to be in the same position as the image to the left. Pull shock mount out slightly from the speaking surface, to reveal additional cabling . Disconnect cable from three prongs by unsoldering.



Lift shock mount up and flip over from the bottom upwards and over so the single solder point is at the top and pair of solder points are oriented on the bottom, as shown.

Referring to the image on the left, match up the three wires with the three solder points, as shown:

Solder 1 (top point of triangle): solder with SILVER ground wire

Solder 2 (bottom left point of triangle): solder with ORANGE wrapped wire

Solder 3 (bottom right point of triangle): solder with WHITE wrapped wire

